




BENNETT

ASSEMBLY INSTRUCTION

|                                                                                          |                                                                                                     |                                                                                          |                                                                                            |                                                                                                       |
|------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------|
| Ax1<br> | Bx1<br>            | Cx1<br> | Dx1<br> | Ex6<br><br>M6x30mm |
| Fx6<br> | Gx4<br><br>M6x16mm | Hx1<br> |                                                                                            |                                                                                                       |

1.

Diagram 1 shows the initial assembly of the chair frame. The rear crossbar (C) and rear support bar (D) are attached to the seat base (A) using screws (E, F) and washers (H).

2.

Diagram 2 shows the seat base (A) being attached to the frame. The seat base is positioned and secured with screws (E, H) and washers (F).

3.

Diagram 3 shows the final assembly of the chair frame. The seat base (A) is fully attached to the frame, and the rear crossbar (C) and rear support bar (D) are secured with screws (E, F) and washers (H).

4.

Diagram 4 shows the final assembled chair. The chair is shown with the seat base (A) and backrest (B) attached to the frame.